

Kinesis Savant Elite2 Firmware Update Instructions

1. Place your SE2 device into “Program Mode” by toggling the switch on the underside of the device. *Note: If you have a stand-alone SE2 Control Module you will need to hold one of the pedals down while plugging the Module into your PC.*
2. Locate the new “KINESIS FP” removable drive in File Explorer (Windows) or Devices (Mac). Open “active” subfolder and then open the version.txt file to determine the version of firmware your SE2 device is currently running.
3. If there is a newer version of firmware available from Kinesis, download the firmware update file.

<https://kinesis-ergo.com/support/savant-elite2/#firmware-updates>

4. Unzip the firmware folder and rename the firmware file “update.upd”.
5. Copy and Paste the renamed “update.upd” file to the “firmware” subfolder on “KINESIS FP”.
6. Right-click “KINESIS FP” and select “Eject”, then unplug your SE2 device.
7. To install the new firmware, hold one pedal down while plugging the SE2 device into your PC. Red and Green lights will flash and this process will take 5-10 seconds.
8. Locate the “active” subfolder on the “KINESIS FP” removable drive and open the version.txt file to confirm the new firmware was installed successfully.
9. If the update was successful, right-click “KINESIS FP” and select “Eject”. Then toggle your SE2 device back to “Play Mode” and resume normal operation.