

## Important Information

### Safety and Regulatory Information

Please go to <http://www.cityergonomics.com/faqs>

### Limitation of Liability

City Ergonomics shall not be responsible for any special, indirect, incidental, or consequential damages whatsoever, including but not limited to loss of profits, revenue or data (whether direct or indirect) or commercial loss for breach of any express or implied warranty on your product even if City Ergonomics has been advised of the possibility of such damages.

### Important Health Information

Use of a keyboard or mouse may be linked to serious injuries or disorders. When using a computer, as with many activities, you may experience occasional discomfort in your hands, arms shoulders, neck, or other parts of your body. If you experience any physical discomfort you should secure advice from a qualified health professional. For more information on healthy computer use go to [www.cityergonomics.com/support](http://www.cityergonomics.com/support)

### Disclaimer

We make every effort to ensure that the information and procedure in this guide is accurate and complete, no liability can be accepted for any omissions and we reserve the right to make any changes without further notice.

### Warranty

The DXT Mouse is guaranteed for a period of 24 months from the date of purchase. For full details please go to <http://www.cityergonomics.com/warranty-and-return-policy>

## Contact Information



### Troubleshooting

Please go to <http://www.cityergonomics.com/faqs>

### Patent Information

US 9,285,898 B2 : US D 647,094 S :Chinese  
3373509 : Europeandesign reg No  
001671025-0001 : Reg Design UK 4012304 :  
UK Patent GB2472880 :

©2017 City Ergonomics Limited.

All Rights Reserved.

<http://www.cityergonomics.com/contact-us>



[www.cityergonomics.com](http://www.cityergonomics.com)



# DXT Mouse 2 Wireless

LIGHT CLICK VERSION  
ERGONOMIC VERTICAL MOUSE  
COMFORT WITH ACCURACY

[www.cityergonomics.com](http://www.cityergonomics.com)

## Getting Started

### WIRELESS VERSION

(for goods with serial number beginning with SNDXTD7001 onwards)

#### • CHARGING:

- Plug USB cable into empty computer USB port and DXT Mouse charging port.
- Charge fully for 2 hours. (To maximize battery life, avoid short bursts of charging)
- To indicate charging the right LED will turn on.
- When fully charged, the right LED will turn off.
- To indicate a low battery the right LED will flash.

#### TO USE:

- Insert USB dongle into USB port.
- Switch on (on/off switch on base of mouse)
- "Sleep mode" If the DXT wireless mouse is not used for approximately 10 minutes, it will go into sleep mode. To reactivate click left or right button.
- "Power off": If the dongle is removed from the computer, the DXT wireless mouse will automatically power off after approximately 24 seconds. To reactivate, click left or right button after inserting dongle back into the computer.
- It is recommended that the mouse is switched off (using the on/off button on the base of the mouse) when the mouse is not in use or in transit.

## Components



## Holding the DXT Mouse

### How to hold the DXT mouse

When holding the mouse, place your thumb in the centre of the curved ridge on the back of it (Figures 1 and 3).

Allow your fingers to curl naturally around the front of the mouse to take up one of the positions shown in (Figures 2 and 4).



## Using the DXT Mouse

### How to change from right to left hand use

You can switch hands by simply pressing the Right/left button on the back of the mouse. Press the button once. The LEDs will flash once to indicate which setting you have selected.

### How to change the speed of the DXT mouse cursor (DPI)

To adjust your DPI setting, press the DPI button on the base of the mouse. The speed setting selected will be indicated by:

1 flash = 500 DPI, 2 flashes = 1000 DPI, 3 flashes = 1500 DPI  
4 flashes = 2000 DPI

### How to connect to a new dongle

(or existing dongle if connection is lost)  
Please refer to the website <http://www.cityergonomics.com/faqs> where details will be provided on how to download the pairing program along with instructions for use.

